

Addendum to COR Module Instructions

Note: Depending on the local microphone you use, if any, the COR board may load down the Exciter audio enough to reduce the modulation when the local mic is used. If you do wish to use a local mic. with your repeater and you do not have sufficient gain in the Exciter audio circuits with the COR board connected to the high level input, you may wish to add a small relay activated by the local mic. ptt switch. Use a pair of normally closed contacts to break the audio path from the COR board when the local mic. is keyed. This also has an additional benefit of muting the repeat audio when you want to break in with the local microphone.