Fig. 5. Basic Set-Up

OSCILLOSCOPE

POWER SUPPLY

FREQUENCY COUNTER

RF SIGNAL GENERATOR

TRANSCEIVER OR RECEIVER

ADJUST FOR 13.8 VDC

RADIO SET POWER CABLE

EXTERNAL SPEAKER JACK

VERTICAL INPUT JACK

INPUT JACK

RF GENERATOR JACK

FREQUENCY COUNTER JACK

OSCILLOSCOPE JACK

ANTENNA JACK

RF OUTPUT JACK

1040 CB SERVICEMASTER

TRANSCEIVER JACK

RECEIVER AUDIO JACKS

AC OUTLET

AC POWER CABLE

13