

CONDENSED PROCEDURE (REFER TO TEXT FOR COMPLETE INSTRUCTIONS)

STEP 1. CONNECT CABLE FROM PA SPEAKER JACK TO RECEIVER AUDIO JACKS

STEP 2. NORMAL PA SPEAKER LOAD

STEP 3. 10 WATTS

STEP 4. 1 kHz

STEP 5. ON

STEP 6. LOUD TONE

STEP 7. PA MODE

STEP 8. PLACE MICROPHONE OVER SPEAKER

STEP 9. CLOSE THE PUSH TO TALK SWITCH

STEP 10. a. VARY MICROPHONE GAIN (IF ADJUSTABLE)

10. b. VARY GAIN

STEP 11. READ AUDIO POWER

STEP 12. a. SET FULL SCALE




12. b. ADJUST FOR FULL SCALE

12. c. ADJ FOR MIN

12. d. ADJUST FOR MINIMUM

12. e. READ % DISTORTION

1040 CB  
SERVICEMASTER



PA SPKR  
JACK  
1

Fig. 21. PA Mode Check