

CONDENSED PROCEDURE (REFER TO TEXT FOR COMPLETE INSTRUCTIONS)

STEP 1. CONNECT AC OR DC POWER CORD TO POWER SOURCE

STEP 2. CONNECT RADIO SET POWER CORD TO POWER SOURCE

STEP 3. POWER ON

STEP 4. CONNECT RADIO TO TRANSCEIVER JACK

STEP 5. CONNECT TO EXT. RF LOAD JACK

STEP 6. SELECT APPROPRIATE RANGE

STEP 7. EXT.

STEP 8. AVG.

STEP 9. FWD.

STEP 10. ON

STEP 11. SELECT CHANNEL 12

STEP 12. AM MODE

STEP 13. KEY TRANSMITTER

STEP 14. READ RF POWER

STEP 15. REV.

STEP 16. READ REVERSE POWER


STEP 17. SET REF.

STEP 18. ADJUST FOR FULL SCALE

STEP 19. READ SWR

STEP 20. READ SWR ON METER

STEP 21. SELECT EACH CHANNEL AND READ SWR.



1040 CB SERVICEMASTER




Fig. 19. Antenna Check and SWR Measurement