

CONDENSED PROCEDURE (REFER TO  
TEXT FOR COMPLETE INSTRUCTIONS)

- STEP 1. INTERCONNECT PER FIG. 5
- STEP 2. AS REQUIRED. 10W FOR CB.
- STEP 3. FWD.
- STEP 4. INT.
- STEP 5. AVG.
- STEP 6. SELECT AM MODE
- STEP 7. SELECT DESIRED CHANNEL
- STEP 8. KEY TRANSMITTER
- STEP 9. READ RF POWER
- STEP 10. READ FREQUENCY




Fig. 7. Transmitter RF Power and Frequency Checks